



# MICROCHIP IMPLANTATION CHECKLIST



STEP 1: Check for pre-existing microchip



STEP 2: Clean the area with either chlorhexidine or betadine solution followed by a little bit of alcohol.



STEP 3: Scan the microchip before implantation to verify the ID number matches the one on the label



STEP 4: Implant the microchip half way between the withers and poll in the nuchal ligament on the left side of the neck, about 1.5-2 inches below the mane line



STEP 5: Rescan the horse to verify the microchip was implanted successfully and that the correct ID number is displayed on the reader

